


## KR 103 Multi Track Recording



- 1) Insert disk
- 2) Press Metronome. Set Metronome tempo by pressing TEMPO gray buttons + / –  
(If time is  $\frac{3}{4}$  select Waltz style, top-left to the screen)
- 3) Press REC (do not play yet) light should be flashing.  
Also screen is flashing with all 16 tracks.
- 4) Select your instrument sound from TONES
- 5) Get ready: at the “click” (beat one) press play, count a whole measure before start playing (“click” -two-three-four if 4/4), start playing. Your playing will be recorded in Track 1  
Press STOP when done.

Get ready to record other parts.

- 6) Press REC again and on the wheel (right to the screen) press ▶ to select track 2 (or other if need it) SOLO
- 7) If needed Select your instrument sound from TONES
- 8) Press PLAY/STOP when ready to play. COUNT 2 measures, then start playing. Previously recorded tracks will play along.
- 9) When done press PLAY/STOP
- 10) If you need to record more tracks repeat 6-8 selecting a new track (track 3, track 4 etc) every time. You can select up to 16 tracks.

### TO SAVE TO DISK

- 11) Press DISK
- 12) Press ENTER (lower right corner of the screen)
- 13) Choose Song # with + /- . If disk is empty number 1 will flash and there will be no name after that. If song is already saved it will show title or ‘song’. Press + on the wheel until empty title  
Press ENTER
- 14) Name song:  
+/- on the wheel to choose letters  
◀▶ to move to next digit  
ENTER and ENTER to save